

JSC-09030

CR 134331

AVIONICS SYSTEMS ENGINEERING DIVISION INTERNAL NOTE

(NASA-CR-134331) MAIN PROPULSION
FUNCTIONAL PATH ANALYSIS FOR PERFORMANCE
MONITORING FAULT DETECTION AND
ANNUNCIATION (Lockheed Electronics Co.)

N74-28231

76 p HC \$7.00

Unclas
CSCL 21H G3/28 42567

77

MAIN PROPULSION FUNCTIONAL PATH ANALYSIS

FOR

PERFORMANCE MONITORING FAULT DETECTION

AND

ANNUNCIATION

~~DISTRIBUTION AND REFERENCING~~

~~This paper is not suitable for general distribution or referencing. It may be referenced only in other working correspondence and documents by participating organizations.~~



National Aeronautics and Space Administration
LYNDON B. JOHNSON SPACE CENTER

Houston, Texas

April 1974

LEC-3193

AVIONICS SYSTEMS ENGINEERING DIVISION INTERNAL NOTE


MAIN PROPULSION FUNCTIONAL PATH ANALYSIS
FOR
PERFORMANCE MONITORING FAULT DETECTION
AND
ANNUNCIATION

PREPARED BY




E. L. Keesler, Principal Engineer
Lockheed Electronics Company, Inc.

APPROVED BY



Robert W. Moorehead
Chief, Communications, Power, and Data Systems Branch



William C. Bradford
Chief, Avionics Systems Engineering Division

NATIONAL AERONAUTICS AND SPACE ADMINISTRATION
LYNDON B. JOHNSON SPACE CENTER
HOUSTON, TEXAS

April 1974

ACKNOWLEDGEMENTS

This document was prepared by Lockheed Electronics Company, Inc., Aerospace Systems Division, Houston, Texas, for the Avionics Systems Engineering Division at the Johnson Space Center, under contract NAS 9-12200, Job Order 22-10. It was written by E. L. Keesler, Principal Engineer, and approved by J. R. Thrasher, Project Manager, Avionics Systems Engineering Department, Lockheed Electronics Company, Inc.

PRECEDING PAGE BLANK NOT FILMED

CONTENTS

Section	Page
1.0 SUMMARY	1-1
2.0 MAIN PROPULSION SYSTEM.	2-1
2.1 Description	2-1
2.1.1 External Tank	2-1
2.1.2 Orbiter Plumbing.	2-1
2.1.3 Main Engines.	2-1
2.1.4 Main Engine Controller.	2-2
2.1.5 Operational Flight Instrumentation (OFI)	2-2
3.0 FUNCTIONAL PATH ANALYSIS.	3-1
3.1 Functional Paths.	3-1
3.1.1 Main Engine No. 1	3-1
3.1.2 Main Engine No. 2	3-6
3.1.3 Main Engine No. 3	3-6
3.2 Pneumatic Helium Supply	3-8
3.2.1 LO ₂ Supply.	3-8
3.2.2 LH ₂ Supply.	3-13
3.3 Engine Monitoring	3-15
3.3.1 Environment	3-16
3.3.2 FDA Measurements.	3-16
4.0 MEASUREMENT TO FUNCTIONAL PATH CORRELATION. . .	4-1
5.0 MEASUREMENT LIMITS FOR FAULT DETECTION AND ANNUNCIATION.	5-1

Section	Page
6.0	TYPICAL MONITORING SEQUENCE. 6-1
7.0	CONCLUSIONS AND RECOMMENDATIONS. 7-1

FIGURES

Figure	Page
1 Engine No. 1, He supply functional paths3-2
2 Engine No. 2, He supply functional paths3-3
3 Engine No. 3, He supply functional paths3-4
4 Pneumatic He supply functional paths3-6
5 Valve actuation supply B manifold functional paths3-9
6 Valve actuation He supply A manifold functional paths3-10
7 LO ₂ monitoring functional paths.3-11
8 LH ₂ monitoring functional paths.3-14
9 Typical preburn He monitor6-2
10 Typical burn He monitor.6-3
11 He supply profile6-4

TABLES

Table		Page
1	ENGINE NO. 1 He SUPPLY	3-17
2	LO ₂ MONITORING FDA	3-21
3	LH ₂ MONITORING FDA	3-25
4	ENVIRONMENT ENGINE COMPARTMENT FDA	3-29
5	CONTROLLER DATA WORDS FOR FDA.	3-30
6	MPS OFI INSTRUMENTATION LIST	3-33
7	PMS MEASUREMENT DATA	4-2
8	PMS MEASUREMENT REQUIREMENTS	5-2

ABBREVIATIONS

Disc	Disconnect
E	Engine
Eng	Engine
GH ₂	Gaseous Hydrogen
GO ₂	Gaseous Oxygen
He	Helium
HPFT	High Pressure Fuel Turbine
HPFTP	High Pressure Fuel Turbo Pump
HPOT	High Pressure Oxidizer Turbine
HPOTP	High Pressure Oxidizer Turbo Pump
LH ₂	Liquid Hydrogen
LO ₂	Liquid Oxygen
ME	Main Engine
OX	Oxidizer
PNEU	Pneumatic
Reg	Regulator
RPM	Revolutions Per Minute
RSV	Relief Shut-off Valve
SOV	Shut-off Valve

1.0 SUMMARY

A total of 48 operational flight instrumentation measurements have been identified for use in performance monitoring and fault detection. Thirty of these measurements are contained in Volume I of the Master Measurements List.

The Operational Flight Instrumentation List, from the main propulsion panel meeting, November 28, 1973, contains all measurements identified for fault detection and annunciation. It is recommended that these measurements be included in the next revision of the Master Measurements List.

In addition, 16 controller data words have been identified for use in fault detection and annunciation. Eight of these data words are not presently in the first 32 data words which will be available to performance monitoring. It is understood that the data word list is being revised to relocate these words.

2.0 MAIN PROPULSION SYSTEM

2.1 Description

The main propulsion system consists of the following:

- External Tank
- Orbiter Plumbing
- Main Engine (three each)
- Main Engine Controller (three each)
- Operational Flight Instrumentation

2.1.1 External tank. The external tank houses propellant for the main engine and provides the structural interface for the launch configuration.

2.1.2 Orbiter plumbing. The Orbiter plumbing provides flow paths and controls for propellant transfer from the external tank to the main engine.

2.1.3 Main engines. The three main engines are reusable hydrogen fuel cooled liquid propellant rocket engines with variable thrust and mixture ratio. Each engine operates at a mixture ratio (liquid oxygen/liquid hydrogen) of 6 to 1, and a chamber pressure of approximately 3000 psia to produce a sea-level thrust of 375,000 pounds and a vacuum thrust of 470,000 pounds. The engines are throttlable over a range of 50 to 109 percent of design thrust level. This provides for high-thrust level during liftoff and early ascent and allows limiting Orbiter acceleration to 3 G's during final ascent. The engines are gimbled to provide Thrust Vector Control.

2.1.4 Main engine controller. Each main engine has a dedicated controller (DCU) which interfaces commands and data between the vehicle and the engine. Main engine fault detection is also provided by the controller.

The controller consists of two identical, independent, stored program, general-purpose, digital computers, each having a self-contained random access memory, arithmetic/control section, and power supply. Each computer has a 16K, 17 bit word, memory capacity.

One controller channel will be active for control. The second channel will be in a monitor mode ready to take the active role on controller command if the active channel fails.

2.1.5 Operational Flight Instrumentation (OFI).
Volume I of the Shuttle Master Measurements List, dated November 16, 1973, defines the instrumentation presently baselined for the Main Propulsion System.

3.0 FUNCTIONAL PATH ANALYSIS

Figures 1 through 8 identify the functional paths of the external tank and Orbiter plumbing of the Main Propulsion System. They are identified to be consistent with the identification used by Rockwell International as defined in Rockwell International internal letter 392-RGM-73-037; dated August 31, 1973; subject, "Documentation of Subsystem Functional Path Analysis."

These functional paths are defined at the component level and identified MEXXX or METX. Various combinations of these functional paths are used together during different mission phases as operating functional paths. The operating functional paths used for performance monitoring during flight are identified OMEXX.


3.1 Functional Paths

3.1.1 Main Engine No. 1. Figure 1 defines the functional paths for Main Engine No. 1 helium supply. Figures 2 and 3 define the paths for Main Engines 2 and 3.

ME 1 is a quick-disconnect check valve used for connecting the helium fill manifold to a ground loading source. The check valve serves as a backup for the four source bottle valves.

ME 2 is a 4.5 cu. ft. helium holding source for Main Engine No. 1. The source pressure is maintained at a pressure of 4000 to 4200 psig and a temperature of 500 to 580° R by a ground source until liftoff minus 30 seconds.

Figure 1. - Engine No. 1 - He supply functional paths.






Figure 2. — Engine No. 2 — He supply functional path.

He MANIFOLD COMMON TO
4 He SUPPLIES




Figure 3. - Engine No. 3 - He supply functional paths.

ME 6 and ME 7 are helium shut-off valves used to isolate the helium source from the engine flow path. Both valves are commanded open by the engine controller just prior to engine start.

The regulator in ME 14 regulates the helium source pressure to engine purge pressure, 750 ± 35 psig. The check valve prevents back flow to the helium source in the event the engine is being supplied from a different source through ME 26.

ME 15 is a burst disc and poppet relief valve to protect the engine from excessive pressure in the event the regulator in ME 14 fails open.

ME 26 is a shut-off valve that connects engine 1 to a helium manifold normally supplied by the pneumatic helium supply, source bottle No. 4. In the event ME 26 is opened, ME 6 and ME 7 are closed.

Helium is used by the engine during burns to purge the cavity between the high-pressure oxidizer turbo pump turbine seals. Approximately 20 psig in the helium line is required to open the helium purge valve. It is assumed that some small blanket pressure will be loaded between the Shut-Off Valves (SOV's) and the engine for leak monitoring prior to liftoff.

P1150C, P1154C, and T1151A provide the required instrumentation for engine No. 1 helium monitoring. The operating functional paths for monitoring engine No. 1 helium are:

OFM 1= (ME 1) (ME 2)

OFM 7= (OFM 1) (ME 6 + ME 7) (ME 14)

The switchable functional path in the event of an OFM 7 failure is (OFM 5) (ME26) (see sec. 3.2, pneumatic supply). Loss of engine purge helium will cause engine shutdown. Source depletion may occur while attempting to isolate transducer failures; therefore, transducer failures should not be considered prior to switching sources during burns.

2.1.2 Main Engine No. 2. Engine No. 2 helium supply (fig. 2) has functional paths identical to those in the engine No. 1 helium supply. The operating functional paths used for performance monitoring FDA are:

OFM 2 = (ME 1) (ME 3)

OFM 8 = (OFM 2) (ME 8 + ME 9) (ME 17)

The switchable functional path in the event of an OFM 8 failure is (OFM 5) (ME 27) (see sec. 3.2).

2.1.3 Main Engine No. 3. Main Engine No. 3, helium supply (see fig. 3) has functional paths identical to those in the engine No. 1 helium supply. The operating functional paths used for performance monitoring FDA are:

OFM 3 = (ME 1) (ME 4)

OFM 9 = (OFM 3) (ME 10 + ME 11) (ME 20)

The switchable functional path in the event of an OFM 9 failure is (OFM 5) (ME 28) (see sec. 3.2).

He MANIFOLD COMMON TO
4 He SUPPLIES




Figure 4. - Pneumatic He supply functional paths.

3.2 Pneumatic Helium Supply

The pneumatic helium supply (fig. 4) has functional paths identical to those in the engine No. 1 helium supply. This fourth helium source supplies pressure to the valves shown in figures 5 and 6. The operating functionals used for performance monitoring FDA are:

OFM 4 = (ME 1) (ME 5)

OFM 5 = (OFM 4) (ME 12 + ME 13) (ME 23)

The switchable functional paths in the event of OFM 5 failure are:

(OFM 3) (ME 28)

or (OFM 2) (ME 27)

or (OFM 1) (ME 26)

2.2.1 LO_2 supply. Three identical operating functional paths supply LO_2 to each engine and return GO_2 to the tank for pressurant. No redundant paths are available for switching. FDA is used to isolate failures in the path that may be corrected by the crew. The operating functional paths for LO_2 flow are (see fig. 7) the following:

Engine No. 1

OFM-10 = (MET 2) (ME 94) (ME 89) (ME 111)
(ME 112 + ME 113) (ME 95) (MET 1)

Engine No. 2

OFM-11 = (MET 2) (ME 94) (ME 90) (ME 115)
(ME 116 + ME 117) (ME 95) (MET 1)




Figure 5. - LO₂ monitoring functional paths.




Figure 6. - LH₂ monitoring functional paths.




Figure 7. - Valve actuation supply B manifold functional paths.

Engine No. 3

OFM-12 = (MET 2) (ME 94) (ME 91) (ME 118)
(ME 119 + ME 120) (ME 95) (MET 1)

MET 2 is the LO₂ tank containing LO₂ and ullage volume for GO₂ tank pressurant. Tank pressure is maintained between 20 and 22 psia. Over pressurization protection is provided by vent valves in MET 5 and MET 6. ME-94 consist of two mutually helium activated shut-off valves at the external tank Orbiter interface. A momentary fail closed of these valves results in the loss of all main engines. ME 89 is a helium activated LO₂ pre valve. A fail closed condition results in loss of one engine. ME 111 consists of two check valves in the engine GO₂ outlet line. The check valves prevent GO₂ backflow through a failed engine. ME 112 is an orifice limiting flow of GO₂ tank pressurant. It is in parallel with ME 113, which is a second orifice and shut-off valve. The shut-off valve of ME 113 is normally open. As tank pressure approaches the upper limit a pressure switch closes the SOV. Tank pressurant flow is then limited to the orifice in ME 112. ME 95 consist of two Orbiter external tank interface shut-off valves for the GO₂ repress line. The tank valve is a close-on disconnect type. The Orbiter side is a helium-actuated shut-off valve. In the event of a fail closed condition, it can be commanded open from the crew panel.

MET 1 is an orifice that provides a final limit to pressurant flow to the tank. Components in the Engine 2 and 3 LO₂ functional paths provide identical functions.

3.2.2 LH_2 supply. Three identical operating functional paths supply LH_2 to each engine and return LH_2 to the tank for pressurant. No redundant paths are available for switching. FDA is used to isolate functional path failures which may be corrected by the crew (fig. 8). The operating functional paths for LH_2 are:

Engine No. 1

OFM 13 = (MET 4) (ME 96) (ME 86) (ME 121)
(ME 122 + ME 123) (ME 98) (MET 3)

Engine No. 2

OFM 14 = (MET 4) (ME 96) (ME 87) (ME 125)
(ME 126 + ME 127) (ME 98) (MET 3)

Engine No. 3

OFM 15 = (MET 4) (ME 96) (ME 88) (ME 128)
(ME 129 + ME 130) (ME 98) (MET 3)

MET 4 is the LH_2 tank containing LH_2 and an ullage volume for GH_2 pressurant. Tank pressure is maintained between 32 and 34 psia. Over pressurization protection is provided by vent valves in MET 7 and MET 8. ME 96 consists of two mutually helium activated shut-off valves, at the external tank Orbiter interface. A momentary fail closed of these valves results in the loss of all main engines. ME 86 is a helium activated LH_2 pre valve. A fail closed condition results in the loss of one engine.

ME 121 consists of two check valves in the engine GH_2 outlet line. The check valves prevent GH_2 back flow through a failed engine. ME 122 is an orifice limiting flow of GH_2 tank pressurant. It is in parallel with ME 123, a second




Figure 8. - Valve actuation He supply A manifold functional paths.

orifice and shut-off valve. The shut-off valve of ME 123 is normally open. As tank pressure approaches the upper limit a pressure switch closes the shut-off valve. Tank pressurant flow is then limited to the orifice in ME 122.

ME 98 consists of two Orbiter external tank interface shut-off valves for the GH_2 repress line. The tank valve is a close on disconnect type. The Orbiter side is a helium activated shut-off valve. In the event of a fail close condition, it can be commanded open from the crew panel.

MET 3 is an orifice that provides a final limit to GH_2 pressurant flow to the tank. Components in the engine 2 and 3 LH_2 functional paths provide identical functions.

3.3 Engine Monitoring

Each engine is monitored by its own dedicated controller during checkout and main engine burns. Failures are compiled in a fault data word. FDA will be used to annunciate these failures to the crew. In addition, seven controller parameters will shut down the engine if their limits are exceeded. In cases where it is desired to insure the engines do not shut down, these limit shut-downs will be inhibited by the crew. FDA will be used to monitor these parameters during the inhibit period. The first 32 data words from each controller are available to PMS. The data word list is presently being revised and it is anticipated that all data words in table 5 will be included in the first 32 data words.

3.3.1 Environment. Engine compartment environment will be monitored by two temperature sensors located in the engine compartment.

3.3.2 FDA measurements. Tables 1 through 5 define the measurements required and their justification for FDA. Those contained in Vol. 1, Part I, of the Master Measurement List (MML), are identified, also those presently assigned to performance monitoring are identified.

The OFI Measurement List, from the main propulsion panel meeting, November 28, 1973, is included as table 6. All measurements identified for FDA by this report are listed in table 6.

TABLE 1. - ENGINE NO. 1 He SUPPLY

Measurement Number	Measurement Identification	Justification for FDA	MML
V41P1150C	E ₁ He Supply Press	Leak detection (preburn) Leak detection (burn)	Part I Software PM - Yes
V41P1154C	E ₁ He Reg. Outlet Press	Leak detection (preburn) Regulator/SOV Failures (burn)	Part I Software PM - Yes
*V41T1151A	E ₁ He Supply Temp	Heat and cold soak preburn leak detection only	Part I Flight PM - Yes

*Needed for ground checkout only
only.

Operating
Functional
Paths

OFM 1 = (ME 1) (ME 2)
OFM 7 = (OFM 1) (ME 6 + ME 7) (ME 14)

TABLE 1. - ENGINE NO. 2 He SUPPLY (Continued)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41P1250C	E ₂ He Supply Press	Leak detection (preburn) Leak detection (burn)	Part 1 Software PM - No
V41P1254C	E ₂ He Reg. Outlet Press	Leak detection (preburn) Regulators/SOV failures (burn)	Part 1 Software PM - Yes
*V41T1251A	E ₂ He Supply Temp.	Heat and cold soak (preburn) Leak detection only	Part 1 Flight PM - Yes
		*Needed for ground checkout only.	
Operating Functional Paths		OFM 2 = (ME 1) (ME 3) OFM 8 = (OFM 2) (ME 8 + ME 9) (ME 17)	

TABLE 1. — ENGINE NO. 3 He SUPPLY (Continued)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41P1350C	E ₃ He Supply Press	Leak detection (preburn) Leak detection (burn)	Part 1 Software PM - No
V41P1354C	E ₃ He Reg. Outlet Press	Leak detection (preburn) Regulator/SOV failures (burn)	Part 1 Software PM - Yes
*V41T1251A	E ₃ He Supply Temp	Heat and cold soak (preburn) Leak detection only	Part 1 Flight PM - Yes
		*Needed for ground checkout only.	
Operational Functional Paths		OFM 3 = (ME 1) (ME 4) OFM 9 = (OFM 3) (ME 10 + ME 11) (ME 20)	

TABLE 1. - PNEUMATIC He SUPPLY (Concluded)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41P1600A	Pneumatic Valve H _e Supply Press	Leak detection (preburn) Leak detection (preburn)	Part 1 Flight PM - Yes
V41P1605A	Pneumatic Valve H _e Reg Outlet Press	Leak detection (preburn) Regulator/SOV Failures (burn)	Part 1 Flight PM - Yes
*V41T1601A	Pneumatic Valve H _e Supply Temp	Heat and cold soak leak detection	Part 1 Flight PM - Yes

*Needed for ground checkout
only.

Operating
Functional
Paths

OFM 4 = (ME 1) (ME 5)
OFM 5 = (OFM 4) (ME 12 + ME 13) ME 23

TABLE 2. - LO₂ MONITORING FDA

Measurement Number	Measurement Identification	Justification for FDA	MML
T41P1750A	LO ₂ Ullage Press #1	Primary repress monitoring and leak detection	Part 1 Flight PM No
T41P1751A	LO ₂ Ullage Press #2	Primary repress monitoring and leak detection	Part 1 Flight PM No
T41P1752A	LO ₂ Ullage Press #3	Primary repress monitoring and leak detection	Part 1 Flight PM No
V41P1130C	E1 LO ₂ Inlet Press	Crew display backup primary inlet monitor	Part 1 Software PM NO
V41P1230C	E ₂ LO ₂ Inlet Press	Crew display backup inlet monitor primary	Part 1 Software PM No

TABLE 2. - LO₂ MONITORING FDA (Continued)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41P1330C	E ₃ LO ₂ Inlet Press	Primary Crew Display backup inlet monitor	Part 1 Software PM No
V41P1354C	LO ₂ Feed Manifold Press	Correlation Crew Display Backup inlet monitor	Part 1 Software PM Yes
V41P1590A	GO ₂ Press Disc.	Correlation Repress fault isolation	Part 1 Flight PM Yes
V41X1516X	GO ₂ Press Disc. Valve Open	Correlation Repress Fault isolation	Part 1 Software PM No
V41X1517X	GO ₂ Press Disc Valve Closed	Correlation Repress fault isolation	

TABLE 2. - LO₂ MONITORING FDA (Continued)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41X1774E	LO ₂ Vent Valve 1 Closed	Correlation Repress fault isolation	
V41X1776E	LO ₂ Vent Valve 1 Open	Correlation Repress fault isolation	
V41X1778E	LO ₂ Vent Valve 2 Closed	Correlation Repress fault isolation	
V41X1780E	LO ₂ Vent Valve 2 Open	Correlation Repress fault isolation	
V41T1161A	E ₁ GH ₂ Outlet Temperature	Correlation Repress fault isolation	
V41T1261A	E ₂ GH ₂ Outlet Temperature	Correlation Repress fault isolation	

TABLE 2. - LO₂ MONITORING FDA (Concluded)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41T1361A	E ₃ GH ₂ Outlet Temperature	Correlation Repress fault isolation	

TABLE 3. - LH₂ MONITORING FDA

Measurement Number	Measurement Identification	Justification for FDA	MML
V41P1300C	E ₃ LH ₂ Eng Inlet Press	Primary Backup crew display Eng. inlet monitor	Part 1 Software PM No
V41P1434C	LH ₂ Feed Manifold Press	Correlation Backup crew display inlet fault detection	Part 1 Software PM Yes
V41P1160A	GH ₂ Outlet Press E ₁	Correlation Repress Failure isolation	
V41P1260A	GH ₂ Outlet Press E ₂	Correlation Repress Failure isolation	
V41P1360A	GH ₂ Outlet Press E ₃	Correlation Repress Failure isolation	

TABLE 3. - LH₂ MONITORING FDA (Continued)

Measurement Number	Measurement Identification	Justification for FDA	MML
T41P1700A	LH ₂ Ullage Press #1	Primary Repress Failure Isolation Leak Detection	Part 1 Flight PM Yes
T41P1701A	LH ₂ Ullage Press #2	Primary Repress Failure Isolation Leak Detection	Part 1 Flight PM Yes
T41P1702A	LH ₂ Ullage Press #3	Primary Repress Failure Isolation Leak detection	Part 1 Flight
V41P1100C	E ₁ LH ₂ Eng. Inlet Press	Primary Backup Crew Disposition Eng. Inlet Monitor	Part 1 Software PM No
V41P1200C	E ₂ LH ₂ Eng. Inlet Press	Primary Backup Crew Disposition Eng. Inlet Monitor	Part 1 Software PM No

TABLE 3. — LH₂ MONITORING FDA (Continued)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41P1490A	GH ₂ Press Disc.	Correlation Repress Failure Isolation	Part 1 Flight PM Yes
T41X1724E	LH ₂ Vent Valve #1 Closed	Correlation Repress Failure Isolation	
T41X1126E	LH ₂ Vent Valve #1 Open	Correlation Repress Failure Isolation	
T41X1744E	LH ₂ Vent Valve #2 Closed	Correlation Repress Failure Isolation	
T41X1746E	LH ₂ Vent Valve #2 Open	Correlation Repress Failure Isolation	

TABLE 3. - LH₂ MONITORING FDA (Concluded)

Measurement Number	Measurement Identification	Justification for FDA	MML
V41X1416E	GH ₂ Press Disc. Valve Open	Correlation Repress Failure Isolation	Part 1 Software PM No
V41X1417E	GH ₂ Press Disc. Valve Closed	Correlation Repress Failure Isolation	

TABLE 4. — ENVIRONMENT ENGINE COMPARTMENT FDA

Measurement Number	Measurement Identification	Justification for FDA	MML
T21 OFI List V41 None	Eng. Comp. Amb. Temp. 1	Over Temp. Monitoring During burns	
T22 OFI List V41 None	Eng. Comp. Amb. Temp. 2	Over Temp. Monitoring During burns	

TABLE 5. - CONTROLLER DATA WORDS FOR FDA

Present Data Word Assignment	Measurement Identification	Justification for FDA	MML
DW-1	Engine Identification	Primary Data Tag	
DW-2	Engine Identification	Primary Data Tag	
DW-3	ME Status	Precondition checks	Part 1 Software PM No
DW-5	Thrust	Correlation for Eng. Inlet Press	Part 1 Software PM No
DW-6	Failure ID	Primary Failure Annunciation	Part 1 Software PM No
DW-7	Test Data	Correlation Fault Annunciation	Part 1 Software PM No

TABLE 5. — CONTROLLER DATA WORDS FOR FDA (Continued)

Present Data Word Assignment	Measurement Identification	Justification for FDA	MML
DW-8	Parameter Value	Correlation Fault Annunciation	
DW-40	HPFTP Disc Temp	Monitoring During Limit Inhibit	Part 1 Software PM No
DW-41	HPFT Shaft Speed	Monitoring During Limit Inhibit	
DW-54	HPOTP Disc. Temp.	Monitoring During Limit Inhibit	Part 1 Software PM No
DW-55	HPOT Boost Stage Press Disc.	Monitoring During Limit Inhibit	
DW-56	HPOT Boost Stage Press Disc.	Monitoring During Limit Inhibit	

TABLE 5. - CONTROLLER DATA WORDS FOR FDA (Concluded)

Present Word Data Word Assignment	Measurement Identification	Justification for FDA	MML
DW-57	HPOT Shaft Speed	Monitoring During Limit Inhibit	Part 1 Software PM No
DW-64	Ox - Tank Pressurant Press	Monitoring During Limit Inhibit	Part 1 Software PM No
DW-65	Ox - Tank Pressurant Press	Monitoring During Limit Inhibit	Part 1 Software PM No
DW-76	HPOT Intermediate Seal Purge Press	Monitoring During Limit Inhibit	

TABLE 6. - MPS OFI INSTRUMENTATION LIST
EXTERNAL TANK PRESSURES AND TEMPERATURES

CODE	MEASUREMENT #	NAME	RANGE	PURPOSE*	S/S
P1T	T41P1750A	LO ₂ Ullage Press #1	0-30 psia	4	10
P2T	T41P1751A	LO ₂ Ullage Press #2	0-30 psia	4	10
P3T	T41P1752A	LO ₂ Ullage Press #3	0-30 psia	4	10
P4T	T41P1700A	LH ₂ Ullage Press #1	0-50 psia	4	10
P5T	T41P1701A	LH ₂ Ullage Press #2	0-50 psia	4	10
P6T	T41P1702A	LH ₂ Ullage Press #3	0-50 psia	4	10
T1T	T41T1755A	LO ₂ Ullage Temp	-430 + 40° F	9	1
T2T	T41T1705A	LH ₂ Ullage Temp	-430 - 40° F	9	1

3-33

*Purpose code defined in Master Measurement List, Volume 1.

TABLE 6. - MPS OFI INSTRUMENTATION LIST
(Continued) EXTERNAL TANK DISCRETES

CODE	MEASUREMENT #	NAME	RANGE	PURPOSE	S/S
X1T	T41X1730X	LH ₂ Depletion Sensor #1		1	10
X2T	T41X1731X	LH ₂ Depletion Sensor #2		1	10
X3T	T41X1732X	LH ₂ Depletion Sensor #3		1	10
X4T	T41X1733X	LH ₂ Depletion Sensor #4		1	10
X6T	T41X1760E	LO ₂ Liquid Level 2% #1		9	10
X7T	T41X1761E	LO ₂ Liquid Level 2% #2		8	10
X8T	T41X1762E	LO ₂ Liquid Level 5%		9	10
X9T	T41X1765E	LO ₂ Liquid Level 98% #1		8	10
X10T	T41X1766E	LO ₂ Liquid Level 98% #2		8	10
X11T	T41X1767E	LO ₂ Liquid Level 99.85%		8	10
X12T	T41X1768E	LO ₂ Liquid Level 100% #1		8	10
X13T	T41X1769E	LO ₂ Liquid Level 100% #2		8	10
X14T	T41X1770E	LO ₂ Liquid Level 100.15%		8	10
X15T	T41X1771E	LO ₂ Liquid Level 102%		8	10
X16T	T41X1710E	LH ₂ Liq Level 2% #1		9	10
X17T	T41X1711E	LH ₂ Liq Level 2% #2		8	10
X18T	T41X1712E	LH ₂ Liq Level 5%		9	
X19T	T41X1715E	LH ₂ Liq Level 98% #1		8	10

TABLE 6. — MPS OFI INSTRUMENTATION LIST (Continued)

EXTERNAL TANK DISCRETES

CODE	MEASUREMENT #	NAME	RANGE	PURPOSE	S/S
X20T	T41X1716E	LH ₂ Liq Level 98% #1		8	10
X21T	T41X1717E	LH ₂ Liq Level 99.7%		8	10
X22T	T41X1718E	LH ₂ Liq Level 100% #1		8	10
X23T	T41X1719E	LH ₂ Liq Level 100% #2		8	10
X24T	T411720E	LH ₂ Liq Level 100.3%		8	10
X25T	T41X1721E	LH ₂ Liq Level 102%		8	10
X26T	T41X1776E	LO ₂ Vent Valve #1 Open		5	10
X27T	T41X1774E	LO ₂ Vent Valve #1 Closed		5	10
X28T	T41X1780E	LO ₂ Vent Valve #2 Open		5	10
X29T	T41X1778E	LO ₂ Vent Valve #2 Closed		5	10
X30T	T41X1726E	LH ₂ Vent Valve #1 Open		5	10
X31T	T41X1724E	LH ₂ Vent Valve #1 Closed		5	10
X32T	T41X1746E	LH ₂ Vent Valve #2 Open		5	10
X33T	T41X1744E	LH ₂ Vent Valve #2 Closed		5	10

TABLE 6. - MPS OFI INSTRUMENTATION LIST (Continued)

ORBITER PRESSURES

CODE	MEASUREMENT #	NAME	RANGE	PURPOSE	S/S
P1	V41P1130C	E ₁ LO ₂ Eng Inlet Press	0-400 psia	9	25
P2	V41P1230C	E ₂ LO ₂ Eng Inlet Press	0-400 psia	9	25
P3	V41P1330C	E ₃ LO ₂ Eng Inlet Press	0-400 psia	9	25
P4	V41P1534C	LO ₂ Feed Manifold Press	0-400 psia	4	10
P5	V41P1100C	E ₁ LH ₂ Eng Inlet Press	0-200 psia	9	25
P6	V41P1200C	E ₂ LH ₂ Eng Inlet Press	0-200 psia	9	25
P7	V41P1300C	E ₃ LH ₂ Eng Inlet Press	0-200 psia	9	25
P8	V41P1434C	LH ₂ Feed Manifold Press	0-200 psia	4	10
P9	V41P1160A	E ₁ GH ₂ Outlet Press	0-5000 psia	4	10
P10	V41P1260A	E ₂ GH ₂ Outlet Press	0-5000 psia	4	10
P11	V41P1360A	E ₃ GH ₂ Outlet Press	0-5000 psia	4	10
P12	V41P1150C	E ₁ H _e Supply Press	0-5000 psia	1	1
P13	V41P1250C	E ₂ H _e Supply Press	0-5000 psia	1	1
P14	V41P1350C	E ₃ H _e Supply Press	0-5000 psia	1	1
P15	V41P1600A	Pneu Valve H _e Supply Press	0-5000 psia	1	10
P16	V41P1154C	E ₁ H _e Reg. Outlet Press	0-1000 psia	4	10
P17	V41P1254C	E ₂ H _e Reg. Outlet Press	0-1000 psia	4	10
P18	V41P1354C	E ₃ H _e Reg. Outlet Press	0-1000 psia	4	10

TABLE 6. — MPS OFI INSTRUMENTATION LIST (Continued)

ORBITER PRESSURES

CODE	MEASUREMENT #	NAME	RANGE	PURPOSE	S/S
P19	V41P1605A	Pneu Valve H _e Reg. Out- let Press	0-1000 psia	4	10
P20	V41P1590A	GO ₂ Press Disc Press	0-1000 psia	4	10
P21	V41P1490A	GH ₂ Press Disc Press	0-1000 psia	4	10
P22		LO ₂ Tank ΔP		8	
P23		LH ₂ Tank ΔP		8	

TABLE 6. — MPS OFI INSTRUMENTATION LIST (Continued)

ORBITER TEMPERATURES					
CODE	MEASUREMENT #	NAME	RANGE	PURPOSE	S/S
T1	V41T1131C	E1 LO ₂ Eng Inlet Temp	-320 to -270° F	9	1
T2	V41T1231C	E2 LO ₂ Eng Inlet Temp	-320 to -270° F	9	1
T3	V41T1331C	E3 LO ₃ Eng Inlet Temp	-320 to -270° F	9	1
*T4	V41T1528A	LO ₂ Feed Manifold Disc Temp	-325 to +125° F	9	1
T5	V41T1101C	E1 LH ₂ Eng Inlet Temp.	-430 to -370° F	9	1
T6	V41T1201C	E2 LH ₂ Eng Inlet Temp	-430 to -370° F	9	1
T7	V41T1301C	E3 LH ₂ Eng Inlet Temp.	-430 to -370° F	9	1
T8	V41T1428A	LH ₂ Feed Manifold Disc Temp	-430 to -379° F	9	1
T9	V41T1171A	E1 GO ₂ Outlet Temp	-250 to +1000° F	9	1
T10	V41T1271A	E2 GO ₂ Outlet Temp	-250 to +1000° F	9	1
T11	V41T1371A	E3 GO ₂ Outlet Temp	-250 to +1000° F	9	1
T12	V41T1591A	GO ₂ Press Disc Temp	-250 to +1000° F	9	1
T13	V41T1161A	E1 GH ₂ Outlet Temp	-65 to +500° F	9	1
T14	V41T1261A	E2 GH ₂ Outlet Temp	-65 to +500° F	9	1
T15	V41T1361A	E3 GH ₂ Outlet Temp	-65 to +500° F	9	1
T16	V41T1491A	GH ₂ Press Disc Temp	-65 to +500° F	9	1
T17	V41T1601A	Pneu Valve H _e Supply Temp	-65 to +500° F	1	1
T18	V41T1151A	E1 H _e Supply Temp	-65 to +500° F	10	1

TABLE 6. — MPS OFI INSTRUMENTATION LIST (Continued)

ORBITER TEMPERATURES

CODE	MEASUREMENT #	NAME	RANGE	PURPOSE	S/S
T19	V41T1251A	E2 H _e Supply Temp	-65 to +500° F	10	1
T20	V41T1351A	E3 H _e Supply Temp	-65 to +500° F	10	1
T21		Eng Comp Amb Temp #1		8	
T22		Eng Comp Amb Temp #2		8	
T23	V41T1060A	E1 Controller H/W Temp	-200 to +400° F	4	1
T24	V41T1061A	E2 Controller H/W Temp	-200 to +400° F	4	1
T25	V41T1062A	E3 Controller H/W Temp	-200 to +400° F	4	1

TABLE 6. - MPS OFI INSTRUMENTATION LIST (Continued)

ORBITER DISCRETES

CODE	MEASUREMENT #	NAME	LOW	HIGH	PURPOSE	S/S
X1	V41X1580X	LO ₂ Depletion Sensor #1	Wet	Dry	1	10
X2	V41X1582X	LO ₂ Depletion Sensor #2	Wet	Dry	1	10
X3	V41X1584X	LO ₂ Depletion Sensor #3	Wet	Dry	1	10
X4	V41X1586X	LO ₂ Depletion Sensor #4	Wet	Dry	1	10
X6	V41X1510E	LO ₂ InB Fill Valve Open			9	
X7	V41X1509X	LO ₂ InB Fill Valve Closed	On	Off	9	10
X8	V41X1413E	LO ₂ OutB Fill Valve Open			9	
X9	V41X1514X	LO ₂ OutB Fill Valve Closed	On	Off	9	10
X10	V41X1409E	LH ₂ InB Fill Valve Open			9	
X11	V41X1410X	LH ₂ InB Fill Valve Closed	On	Off	9	10
X12	V41X1413E	LH ₂ OutB Fill Valve Open			9	
X13	V41X1414X	LH ₂ OutB Fill Valve Closed	On	Off	9	10
X14	V41X1553E	LH ₂ Topping Fill Valve Open			9	
X15	V41X1456X	LH ₂ Topping Fill Valve Closed			9	
X16	V41X1134X	E1 LO ₂ Pre Valve Open	On	Off	9	10
X17	V41X1234X	E2 LO ₂ Pre Valve Open	On	Off	9	10

TABLE 6. — MPS OFI INSTRUMENTATION LIST (Continued)

ORBITER DISCRETES

CODE	MEASUREMENT #	NAME	LOW	HIGH	PURPOSE	S/S
X18	V41X1334X	E3 LO ₂ Pre Valve Open	On	Off	9	10
X19	V41X1135E	E1 LO ₂ Pre Valve Closed	On	Off	9	10
X20	V41X1235E	E2 LO ₂ Pre Valve Closed			9	
X21	V41X1335E	E3 LO ₂ Pre Valve Closed			9	
X22	V41X1104X	E1 LH ₂ Pre Valve Open	On	Off	9	10
X23	V41X1204X	E2 LH ₂ Pre Valve Open	On	Off	9	10
X24	V41X1304X	E3 LH ₂ Pre Valve Open	On	Off	9	10
X25	V41X1105E	E1 LH ₂ Pre Valve Closed			9	10
X26	V41X1205E	E2 LH ₂ Pre Valve Closed	On	Off	9	10
X27	V41X1305E	E3 LH ₂ Pre Valve Closed			9	
X28	V41X1109E	E1 LH ₂ Recirc Valve Open	On	Off	8	10
X29	V41X 1209E	E2 LH ₂ Recirc Valve Open	On	Off	8	10
X30	V41X1309E	E3 LH ₂ Recirc Valve Open	On	Off	8	10
X31	V41X1110E	E1 LH ₂ Recirc Valve Closed	On	Off	8	10
X32	V41X1210E	E2 LH ₂ Recirc Valve Closed	On	Off	8	10
X33	V41X1310E	E3 LH ₂ Recirc Valve Closed	On	Off	8	10

TABLE 6. - MPS OFI INSTRUMENTATION LIST (Continued)

ORBITER DISCRETES

CODE	MEASUREMENT #	NAME	LOW	HIGH	PURPOSE	S/S
*X34	V41X1545E	LO ₂ RSV Open			9	10
X35	V41X1546X	LO ₂ RSV Closed			9	10
X36	V41X1445E	LH ₂ RSV Open			9	10
X37	V41X1446E	LH ₂ RSV Closed			9	10
X38	V41X1529X	LO ₂ F/L Disc Valve Open	On	Off	9	10
X39	V41X1530E	LO ₂ F/L Disc Valve Closed			9	10
X40	V41X1429X	LH ₂ F/L Disc Valve Open	On	Off	9	10
X41	V41X1430E	LH ₂ F/L Disc Valve Closed			9	10
X42	V41X1419E	LH ₂ Recirc Disc Valve Open	On	Off	4	10
X43	V41X1420E	LH ₂ Recirc Disc Valve Closed			4	10
X44	V41X1516X	GO ₂ Press Disc Valve Open	On	Off	9	10
X45	V41X1517E	GO ₂ Press Disc Valve Closed			9	10
X46	V41X1415E	GH ₂ Press Disc Valve Open			9	
X47	V41X1417E	GH ₂ Press Disc Valve Closed			9	

TABLE 6. - MPS OFI INSTRUMENTATION LIST (Concluded)
ORBITER SPEEDS

CODE	MEASUREMENT #	NAME	UNITS	PURPOSE	S/S
R1	V41R1115A	E1 LH ₂ Recirc Pump Speed	RPM	5	10
R2	V41R1215A	E2 LH ₂ Recirc Pump Speed	RPM	5	10
R3	V41R1315A	E3 LH ₂ Recirc Pump Speed	RPM	5	10

4.0 MEASUREMENT TO FUNCTIONAL PATH CORRELATION

The operational instrumentation measurements required for FDA are compiled in table 7. The normal operating range, functional path correlation, and mission phases to be monitored are also tabulated.

TABLE 7. - PMS MEASUREMENT DATA

MAIN PROPULSION SUBSYSTEM

MEASUREMENT	TYPE*	RANGE	FUNCTIONAL PATH	REMARKS
T1151A	P*	500 - 580° R	ME 2	Preburn only
P1150C	P	(See fig. 9)	OFM 7	Curve fit for burns
P1154C	P	715 - 785 PSIA	OFM 7	
T1251A	P	500 - 580° R	ME 3	Preburn only
P1250C	P	(See fig. 9)	OFM 8	Curve fit for burns
4-2 P1254C	P	715 - 785 PSIA	OFM 8	
T1351A	P	500 - 580° R	ME 4	Preburn only
P1350C	P	(See fig. 9)	OFM 9	Curve fit for burns
P1354C	P	715 - 785 PSIA	OFM 9	
T1601A	P	500 - 580° R	ME 5	Preburn only
P1600C	P	(See fig. 9)	OFM 5	Profile fit
P1605C	P	715 - 785 PSIA	OFM 5	
Controller DW 5				See Table 5

*p = Primary

TABLE 7. - PMS MEASUREMENT DATA
MAIN PROPULSION SUBSYSTEM (Continued)

MEASUREMENT	TYPE	RANGE	FUNCTIONAL PATH	REMARKS
T41P1750A	P	20-27 psia	OFM 10-11-12	Vote 2 of 3 = good.
T41P1751A	P	20-27 psia	OFM 10-11-12	Vote 2 of 3 = good.
T41P1752A	P	20-27 psia	OFM 10-11-12	Vote 2 of 3 = good.
V41P1590A	S*	1000 - 5500 psia	OFM 10-11-12	Max. Min. limit PM limit may be different.
V41X1516X	S	Event	OFM 10-11-12	
V41X1517X	S	Event	OFM 10-11-12	
V41X1774E	S	Event	OFM 10-11-12	
V41X1776E	S	Event	OFM 10-11-12	
V41X1778E	S	Event	OFM 10-11-12	
4-3 V41X1780E	S	Event	OFM 10-11-12	
V41P1130C	P	23.3 - 375 psia	OFM 10	Max. Min. limits may be difficult.
V41P1230C	P	23.3 - 375 psia	OFM 11	Max. Min. limits may be difficult.
V41P1330C	P	23.3 - 375 psia	OFM 12	Max. Min. limits may be difficult.
V41P1534C	S	23.3 - 375 psia	OFM 10-11-12	Max. Min. limits may be difficult.
V41P1700A	P	32-39 psia	OFM 13-14-15	Vote 2 of 3 = good.
V41P1701A	P	32-39 psia	OFM 13-14-15	Vote 2 of 3 = good.
V41P1702A	P	32-39 psia	OFM 13-14-15	Vote 2 of 3 = good.
V41P1100C	P	20-130 psia	OFM 13	Limits are Min. and Max. spike. Require further refinement.

*S = Correlation

TABLE 7. - PMS MEASUREMENT DATA
MAIN PROPULSION SUBSYSTEM (Continued)

MEASUREMENT	TYPE	RANGE	FUNCTIONAL PATH	REMARKS
V41P1200C	P	20-130 psia	OFM 14	Limits are Min. and Max. spike. Require further refinement.
V41P1300C	P	20-130 psia	OFM 15	Limits are Min. and Max. spike. Require further refinement.
V41P1434C	S	20-130 psia	OFM 13-14-15	
V41X1726E	S		OFM 13-14-15	
V41X1724E	S		OFM 13-14-15	
V41X1746E	S		OFM 13-14-15	
V411744E	S		OFM 13-14-15	
V41X1516E	S		OFM 13-14-15	
V41X1517E	S		OFM 13-14-15	
V41X1490A	S	1500 4500 psia	OFM 13-14-15	Max. Min. limit PM limit may be different
V41P1160A	S	TBD	OFM 13	
V41P1260A	S	TBD	OFM 14	
V41P1360A	S	TBD	OFM 15	
V41S1611E	Precond.	On - Off		Precondition check
V41S1613E	Precond.	On - Off		Precondition check
V411616E	Precond.	On - Off		Precondition check
V41S1613E	Precond.	On - Off		Precondition check
V41S1616E	Precond.	On - Off		Precondition check
T21 (OFI List)				Environment
T22 (OFI List)				Environment

5.0 MEASUREMENT LIMITS FOR FAULT DETECTION AND ANNUNCIATION

Table 8 defines the hard limits to be used for FDA, and the correlation checks required in the event a primary measurement fails the hard limit check.

Soft limits have not been included since they are not yet defined.

TABLE 8. - PMS MEASUREMENT REQUIREMENTS

SUBSYSTEM: <u>Main Propulsion</u>			F D A									
<div>PMS ACTIVITY</div> <div><u>SYSTEM DATA:</u><ul style="list-style-type: none">● MEASUREMENT NO.● MEASUREMENT ID● FUNCTIONAL PATH</div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT	
	HARDWARE STATUS	CONFIGURATION CHECK										
			HIGH	LOW		HIGH	LOW	HIGH	LOW			
<ul style="list-style-type: none">● V41P1350C (P)<ul style="list-style-type: none">● E₃ He Supply P● OFM 9● V41P1354C (P)<ul style="list-style-type: none">● E₃ He Reg Outlet P● OFM 9● T1601A (S)<ul style="list-style-type: none">● Pneu Valve He● ME 5● V41P1600A (P)<ul style="list-style-type: none">● Pneu Valve● He Supply Press● OFM 5						Fig. 11				1351 1354		
						715 psia	785 psia					
						500°R	580°R					
						Fig. 11				1601 1605		

TABLE 8. - PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: Main Propulsion

(continued)

SUBSYSTEM: Main Propulsion		F D A									
PMS ACTIVITY	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT
	HARDWARE STATUS	CONFIGURATION CHECK									
			HIGH	LOW		HIGH	LOW	HIGH	LOW		
<div>SYSTEM DATA:</div> <div><div>● MEASUREMENT NO.</div><div>● MEASUREMENT ID</div><div>● FUNCTIONAL PATH</div></div>											
<div><div>● V41P1605A (P)</div><div>● Pneu Valve He Outlet Reg Press</div><div>● OFM 5</div><div>● Controller (Pre-cond)</div><div>● Data Word 1</div><div>● Eng Status</div></div>						715 psia	785 psia				
<div><div>● V41T1151A (S)</div><div>● E1 He Supply Temp.</div><div>● ME2</div></div>						500°R	580°R				
<div><div>● V41P1150C (P)</div><div>● E1 He Reg. Outlet</div><div>● OFM 7</div></div>						Fig. 11					1151 1154
<div><div>● V41P1154C (P)</div><div>● E1 He Reg. Outlet</div><div>● OFM 7</div></div>						715 psia	785 psia				

TABLE 8. - PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: <u>Main Propulsion</u>			F D A								
<div>PMS ACTIVITY</div> <div><u>SYSTEM DATA:</u><ul style="list-style-type: none">● MEASUREMENT NO.● MEASUREMENT ID● FUNCTIONAL PATH</div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT
	HARDWARE STATUS	CONFIGURATION CHECK									
			HIGH	LOW		HIGH	LOW	HIGH	LOW		
<ul style="list-style-type: none">● V41T1251A (S)● E2 He Supply Temp● ME 3						500	580°R				
<ul style="list-style-type: none">● V41P1250C (P)● E1 He Supply● OFM 8						Fig. 11					1251 1254
<ul style="list-style-type: none">● V41P1254C (P)● E2 He Reg Outlet● OFM 8						715 psia	785 psia				
<ul style="list-style-type: none">● V41T1351A (S)● E3 He Supply Temp						500°R	580°R				
<ul style="list-style-type: none">● V41S1611E (S)● Pneu 1 Cross● Over Open Cmd.											

TABLE 8. — PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: Main Propulsion

SUBSYSTEM: <u>Main Propulsion</u>		F D A									
<div>PMS ACTIVITY</div> <div>SYSTEM DATA:<ul style="list-style-type: none">● MEASUREMENT NO.● MEASUREMENT ID● FUNCTIONAL PATH</div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT
	HARDWARE STATUS	CONFIGURATION CHECK	HIGH	LOW		HIGH	LOW	HIGH	LOW		
<ul style="list-style-type: none">● V41S1613E (S)● Pneu 2 Cross Over Open Cmd.● V41S1616E (S)● Pneu 3 Cross Over Open Cmd.● V41X1776E (S)● LO₂ Vent Valve 1²Open● OFM 10-11-12● V41X1778E (S)● LO₂ Vent Valve 2²Closed● OFM 10-11-12											

TABLE 8. — PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: Main Propulsion

SUBSYSTEM: <u>Main Propulsion</u>			F D A									
<div><div>PMS ACTIVITY</div><div>SYSTEM DATA:<ul style="list-style-type: none">● MEASUREMENT NO.● MEASUREMENT ID● FUNCTIONAL PATH</div></div>	PRE — CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT	
	HARDWARE STATUS	CONFIGURATION CHECK										
			HIGH	LOW		HIGH	LOW	HIGH	LOW			
<ul style="list-style-type: none">● V41P1534C (S) ● LO₂ Feed Manifold Press ● OFM 10-11-12● T41P1750A (P) ● LO₂ Ullage P1 ● OFM 10-11-12● T41P1751A (P) ● LO₂ Ullage P2 ● OFM 10-11-12● T41P1752A (P) ● LO₂ Ullage P3 ● OFM 10-11-12						27 psia	20 psia			1590 1774 1776 1778 1780		
						27 psia	20 psia			1590 1774 1776 1778 1780		
						27 psia	20 psia			1590 1774 1776 1778 1780		

TABLE 8. - PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: Main Propulsion

<div> PMS ACTIVITY </div> <div> SYSTEM DATA: ● MEASUREMENT NO. ● MEASUREMENT ID ● FUNCTIONAL PATH </div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT
	HARDWARE STATUS	CONFIGURATION CHECK	HIGH	LOW		HIGH	LOW	HIGH	LOW		
<div> ● V41P1590A (S) ● GO₂ Disc Press ● OFM 10-11-12 </div>						5500 psia	1000 psia			1516 1517	
<div> ● V41X1516X (S) ● GO₂ Press Disc Valve Open ● OFM 10-11-12 </div>											
<div> ● V41X1517X (S) GO₂ Press Disc Valve Closed ● OFM 10-11-12 </div>											
<div> ● V41X1774E (S) LO₂ Vent Valve 1 Closed ● OFM 10-11-12 </div>											

TABLE 8. - PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: Main Propulsion

(Continued)

SUBSYSTEM: <u>Main Propulsion</u>		F D A									
<div>PMS ACTIVITY</div> <div><u>SYSTEM DATA:</u><ul style="list-style-type: none">● MEASUREMENT NO.● MEASUREMENT ID● FUNCTIONAL PATH</div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT
	HARDWARE STATUS	CONFIGURATION CHECK									
			HIGH	LOW	HIGH	LOW	HIGH	LOW			
<ul style="list-style-type: none">● T41X1746E (S) LH₂ Vent Valve● 2 Open● OFM 13-14-15						TBD	TBD				
<ul style="list-style-type: none">● V41P1160A (S) GH₂ Outlet● Press E1● OFM 13						TBD	TBD				
<ul style="list-style-type: none">● V41P1761A (S) GH₂ Outlet● Press E2● OFM 14						TBD	TBD				
<ul style="list-style-type: none">● V41P1361A (S) GH₂ Outlet● Press E3● OFM 15						TBD	TBD				

TABLE 8. - PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: Main Propulsion

(continued)

SUBSYSTEM: <u>Main Propulsion</u>		F D A									
<div>PMS ACTIVITY</div> <div><u>SYSTEM DATA:</u><ul style="list-style-type: none">● MEASUREMENT NO.● MEASUREMENT ID● FUNCTIONAL PATH</div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT
	HARDWARE STATUS	CONFIGURATION CHECK									
			HIGH	LOW		HIGH	LOW	HIGH	LOW		
<ul style="list-style-type: none">● V41X1416E (S) GH₂ Press Disc● Valve Open● OFM 13-14-15											
<ul style="list-style-type: none">● V41X1417E (S) GH₂ Press Disc● Valve Closed● OFM 13-14-15											
<ul style="list-style-type: none">● V41P1434C (S) LN₂ Feed● Manifold Press● OFM 13-14-15						130 psia	20 psia				
<ul style="list-style-type: none">● V41P1700A (P) LH₂ Ullage P1● OFM 13-14-15						39 psia	32 psia			1490 1724 1726 1744 1746	

01-5/

TABLE 8. - PMS MEASUREMENT REQUIREMENTS
(Continued)

SUBSYSTEM: Main Propulsion

SUBSYSTEM: <u>Main Propulsion</u>		F D A									
<div>PMS ACTIVITY</div> <div>SYSTEM DATA:<ul style="list-style-type: none">MEASUREMENT NO.MEASUREMENT IDFUNCTIONAL PATH</div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT
	HARDWARE STATUS	CONFIGURATION CHECK									
			HIGH	LOW		HIGH	LOW	HIGH	LOW		
<ul style="list-style-type: none">V41P1701A (P)<ul style="list-style-type: none">LH₂ Ullage P2OFM 13-14-15V41P1702A (P)<ul style="list-style-type: none">LH₂ Ullage P3OFM 13-14-15V41P1490A (S)<ul style="list-style-type: none">GH₂ Press DiscOFM 13-14-15T41X1724E (S)<ul style="list-style-type: none">LH₂ Vent Valve1 OpenOFM 13-14-15						39 psia	32 psia			1490 1724 1726 1744 1746	
						39 psia	32 psia			1490 1724 1726 1744 1746	
						4500 psia	1500 psia			1416 1417 1160 1260 1360	

11-5

TABLE 8. - PMS MEASUREMENT REQUIREMENTS
(Concluded)

SUBSYSTEM: Main Propulsion

(Concluded)

SUBSYSTEM: <u>Main Propulsion</u>			F D A									
<div>PMS ACTIVITY</div> <div><u>SYSTEM DATA:</u><ul style="list-style-type: none">● MEASUREMENT NO.● MEASUREMENT ID● FUNCTIONAL PATH</div>	PRE— CONDITION TEST		SOFT LIMIT CHECK		TREND CHECK	HARD LIMIT CHECK		BACKUP CAUTION & WARNING		CORRELATION CHECK	SYSTEM STATUS LIGHT	
	HARDWARE STATUS	CONFIGURATION CHECK										
	HIGH	LOW	HIGH	LOW	HIGH	LOW						
<ul style="list-style-type: none">● T41X1726E (S) LH₂ Vent Valve● 1 Open● OFM 13-14-15												
<ul style="list-style-type: none">● T41X1744E (S) LH₂ Vent Valve● 2 Closed● OFM 13-14-15												
<ul style="list-style-type: none">● V41P1100C (P) E1 LH₂ Eng. Inlet Press						130 psia	20 psia			1434		
<ul style="list-style-type: none">● V41P1200C (P) E2 LH₂ Eng. Inlet Press● OFM 14						130 psia	20 psia			1434		
<ul style="list-style-type: none">● V41P1300C (P) E3 LH₂ Eng. Inlet Press● OFM 15						130 psia	20 psia			1434		

6.0 TYPICAL MONITORING SEQUENCE

Figures 9 and 10 show a typical type of monitoring sequence required for different mission phases.

Figure 11 demonstrates the type of parameter versus time monitoring that will be required.




Figure 9. — Typical preburn He monitor enter from precondition.




Figure 10. — Typical burn He monitor enter from precondition.




Figure 11. - Typical pneumatic system storage bottle pressure histories.

7.0 CONCLUSIONS AND RECOMMENDATIONS

The Master Measurements List, dated November 16, 1973, is not adequate for Main Propulsion Fault Detection and Annunciation.

The following measurements from the Operational Flight Instrumentation List, presented at the November 28 main propulsion panel meeting, should be added to the Master Measurements List, for the fault detection and annunciation:

V41X1517X	GO ₂ Press Disc Valve Closed
V41X1774E	LO ₂ Vent Valve 1 Closed
V41X1776E	LO ₂ Vent Valve 1 Open
V41X1778E	LO ₂ Vent Valve 2 Closed
V41X1780E	LO ₂ Vent Valve 2 Open
V41T1161A	E ₁ GH ₂ Outlet Temp.
V41T1261A	E ₂ GH ₂ Outlet Temp.
V41T1361A	E ₃ GH ₂ Outlet Temp.
V41P1160A	E ₁ GH ₂ Outlet Press
V41P1260A	E ₂ GH ₂ Outlet Press
V41P1360A	E ₃ GH ₂ Outlet Press
T41X1724E	LH ₂ Vent Valve 1 Closed
T41X1126E	LH ₂ Vent Valve 1 Open
T41X1744E	LH ₂ Vent Valve 2 Closed
T41X1746E	LH ₂ Vent Valve 2 Open
V41X1417E	GH ₂ Press Disc Valve Closed
No Assign Number	Eng. Comp. Amb. Temp. 1
No Assign Number	Eng. Comp. Amb. Temp. 2

All Measurements identified for fault detection and annunciation, in this document, should be made available to Performance Monitor.

In addition it is recommended that the controller data word list be revised. The 16 data words identified in table 5 should be included in the first 32 controller data words since only the first 32 words are available to Performance Monitor.